



1	8889429	FRAME ASSEMBLY	21	8890088	LATCH SCREW	41	8889474	TENSION SPRING	61	8889495	ARBOR SPRING
2	8889430	LOCKER SPRING	22	8889451	LATCH SCREW WASHER	42	8889475	TENSION SHIM	62	8889496	BRAKE SHOE
3	8889431	LOCKER	23	8889452	LATCH	43	8889476	TENSION RUBBER	63	8889497	BRAKE HOUSING
4	8889432	CARRIER GUIDE	24	8889453	PINION YOKE	44	1078912	TENSION KNOB	64	8889498	RING
5	8889433	CARRIER GUIDE S/C WASHER	25	8889454	YOKE SPRING	45	8889478	CLUTCH BEARING	65	8889499	SPOOL COVER
6	8890087	CARRIER GUIDE SCREW	26	8889455	PINION GEAR	46	8889479	SLEEVE	66	8889501	SPOOL COVER SCREW
7	8889435	E-CLIP	27	8889456	BEARING PLATE	47	8889481	WAVE WASHER	67	8889502	BALL BEARING
8	8889436	CARRIER	28	8889457	BEARING PLATE SCREW	48	8889482	DRAG NUT	68	8889503	RING
9	8889437	PAWL	29	8889458	BEARING PLATE SCREW	49	8889483	DRAG NUT SPRING	69	8889504	SPOOL COVER WASHER
10	8889438	PAWL CAP WASHER	30	8889459	BALL BEARING	50	8889484	STAR DRAG	70	8889505	KEY SCREW
11	8889439	PAWL CAP	31	8889462	CRANK SHIRT	51	8889485	HANDLE ASSEMBLY	71	8889506	KEY
12	8889440	WORK SHIRT	32	8889463	O/S GEAR	52	8889486	HANDLE NUT	72	8890091	LEFT SIDE COVER
13	8889441	WORK SHIRT BUSHING	33	8889464	LATCH GEAR	53	8889487	HANDLE NUT CAP	73	8889508	BUTTON SPRING
14	8889442	O/S PINION	34	8889465	SPACER WASHER	54	8889488	CAP SCREW	74	8889509	BUTTON
15	8889443	E-CLIP	35	8889466	DRIVE GEAR	55	8889489	PLATE SPRING			
16	8889444	THUMB BAR	36	8889467	DRAG "B" WASHER	56	8889490	PLATE			
17	8889445	KICKER	37	8889468	DRAG "D" WASHER	57	8889491	SPOOL CAP			
18	8889446	KICKER SPRING	38	8889469	RIGHT SIDE COVER	58	8889492	SPOOL CAP SCREW			
19	8889447	FLOPPIN LEVER	39	8889471	RIGHT SIDE COVER SCREW	59	8889493	SPOOL			
20	8889448	FLOPPIN LEVER S/P	40	8889472	BALL BEARING	60	8889494	ARBOR ASSEMBLY			

63