



TRITON
SpeedMaster II 90

TO ORDER: USE TGT PREFIX
WITH PART NUMBER

PARTS LIST

TGT #	DESCRIPTION	TGT #	DESCRIPTION	TGT #	DESCRIPTION
0014	Lock Washer	0091	Bearing Thrust Washer	0189	Clutch Lever
0024	Eared Washer "E"	0092	Drag Spring Washers	0190	Clutch Spring
0026	Eared Washer "B"	0104	Yoke Spring	0191	Clutch Cam
0031	Drive Shaft Bushing	0109	Right Side Plate Screw (B)	0192	Side Plate Bushing
0032	Spacer	0111	Click Gear Retainer	0193	Key Washer "F ₂ "
0033	Drive Shaft Retainer	10130C	Handle Assembly	0194	Drive Gear
0037	Anti-Reverse Pawl	0138	"O" Ring	0195	Pinion Gear
0039	Anti-Reverse Pawl Spring	0157	Drag Washer "G"	0196	Yoke
0041	Yoke Plate	0158	Drag Washer "I"	0199	Left Side Plate
0052	Ball Bering	0159	Key Washer "F"	0200	Left Side Plate Screw
0054	Click Gear	0161	Drive Shaft Washer	0201	Click Button
0058	Spacer "B"	0162	Anti-Reverse Ratchet	0202	Rod Clamp
0062	Click Pawl Retainer	0180	Cast Control Cap	0203	Rod Clamp Bolt
0063	Click Pawl	0181	Drag Spring Washer	0234	Handle Nut Plate Screw
0065	Spacer A	0182	Cast Control Spacer	0235	Handle Nut Plate
0067	Click Spring	0183	Felt Washer	0236	Star Drag
0068	Click Spring Screw	0184	Ball Bearing	0237	Star Drag Washer
0070	Spacer B	0185	"O" Ring	0238	Drive Shaft
0076	Handle Nut	0186	Bushing Screw	0239	Frame
0078	Handle Washer	0187	Right Side Plate Screw (A)	0240	Bearing Thrust Washer
0087	Clutch Lever Screw	0188	Right Side Plate	0241	Spool
0090	Ball Bearing				

Prices and specifications subject to change without notice