



EXPLODED PARTS VIEW

TRITON *SpeedMaster* TSM III FS
with *Fightin' Star*™

PARTS LIST

PART #	DESCRIPTION	PART #	DESCRIPTION	PART #	DESCRIPTION
TGT 0014	Lock Washer	TGT 0086	Spool Tension Spring	TGT 0110	Spool
TGT 0016	Clutch Spring	TGT 0087	Clutch Lever Screw	TGT 0111	Click Gear Retainer
TGT 0031	Drive Shaft Bushing	TGT 0088	Clutch Lever	TGT 0112	Ball Bearing
TGT 0033	Drive Shaft Retainer	TGT 0089	Clutch Cam	TGT 0113	Left Side Plate
TGT 0037	Anti-Reverse Pawl	TGT 0090	Ball Bearing	TGT 0114	Left Side Plate Screw
TGT 0039	Anti-Reverse Pawl Spring	TGT 0091	Bearing Thrust Washer	TGT 0115	Click Button
TGT 0041	Yoke Plate	TGT 0092	Drag Spring Washer	TGT 0145	Friction Washer
TGT 0052	Ball Bearing	TGT 0093	Key Washer "F"	TGT 0146	Pre-Set Dial
TGT 0054	Click Gear	TGT 0094	Drag Washer "D"	TGT 0147	Pre-Set Spring
TGT 0058	Spacer "B"	TGT 0095	Eared Washer "E"	TGT 0148	Pre-Set Nut
TGT 0062	Click Pawl Retainer	TGT 0096	Drag Washer "I"	TGT 0149	Strike
TGT 0063	Click Pawl	TGT 0097	Key Washer "C"	TGT 0150	Strike Spring
TGT 0065	Spacer A	TGT 0098	Eared Washer "B"	TGT 0151	Strike Spacer
TGT 0067	Click Spring	TGT 0099	Drive Gear	TGT 0152	Strike Ball
TGT 0068	Click Spring Screw	TGT 0100	Drive Shaft Washer	TGT 0153	Star Drag
TGT 0070	Spacer B	TGT 0101	Anti-Reverse Ratchet	TGT 0170	Handle Nut Plate Screw
TGT 0076	Handle Nut	TGT 0103	Pinion Gear	TGT 0171	Handle Nut Plate
TGT 0081	Right Side Plate Screw (A)	TGT 0104	Yoke Spring	TGT 0172	Handle Assembly
TGT 0082	Spool Shaft Bushing	TGT 0105	Yoke	TGT 0173	Drive Shaft Cam
TGT 0083	Right Side Plate	TGT 0107	Line Guard	TGT 0174	Drive Shaft
TGT 0084	Cast Control Cap	TGT 0108	Line Guard Screw	TGT 0175	Frame
TGT 0085	Spacer	TGT 0109	Right Side Plate Screw (B)	TGT 0176	Spacer